

## Free Standing Jib Crane Bottom Entry Collector Installation Instructions

## **Bottom Entry Collector for FS300, FS350 & FS350S**

- 1. Connect wires protruding from the mast pivot pin to the collector wires. Be sure to connect the same color wires to each other.
- 2. Place collector over top of the mast pivot pin (and collector adaptor if applicable) making sure the connected wires are pushed down inside mast pipe.
- 3. Lock collector in place by tightening the set screws at the base of the collector.
- 4. Connect the collector to the bolt mounted in the weight bearing channel by using the stabilizing arm and hardware kit provided.
- 5. Add appropriate size hole in the collector cover or front of weight bearing channel to allow installation of hoist power cable to collector.
- 6. Attach collector cover with mounting hardware provided.

Refer to drawing BECA for additional references.